
Fuel Line & Wiring Diagram



6 Pole 2 Position Switch info@imcomarine.com