## 1" SCX SPACER 01-8052 ASSEMBLY INSTRUCTIONS

- 1. Remove old (short) studs, 4 ea. on the upper housing, 2 ea. on the lower case.
- Install new studs (longer), use provided loctite.
  Place spacer on lower case, check that all "O" rings are in place and not damaged.
  Install alignment spacer and provided "O" rings on top side of spacer.
- 5. Install coupler.
- 6. Assemble lower unit to upper housing.
- 7. Tighten nuts.



510 East Arrow Hwy San Dimas, CA 91773 (800) 899-8058 (909) 592-6162 Fax (909) 592-6052 info@imcomarine.com www.imcomarine.com

Qty

1

1

1

1

1

1

4

2

8

8

1

1

Part Number

01-2453

11-2014

11-4011

11-2143

11-2144

01-2401

01-2142

09-2038

08-130904181

08-130904161

08-100900001

08-080904001

