1" SC SPACER 0-1" LOWER ASSEMBLY INSTRUCTIONS

- Remove old (short) studs, 4 ea. on the upper housing, 2 ea. on the lower case.
 Install new studs (longer), use provided loctite.
 Place spacer on lower case, check that all "O" rings are in place and not damaged.
- 4. Inst
- 5. Inst
- 6. Ass
- 7. Ass
- 7. Tig

(800)



| Install alignment bushing and provided "O" rings on top side of spacer. Install coupler. Assemble lower unit to upper housing. Assemble 3/8" Socket Set Screw through upper case. Tighten nuts. | | | | |
|---|-----------|--------------------------------------|-----|--------------|
| | | Kit Part # 01-8105 | | |
| | Item | Description | Qty | Part Number |
| | 1 | Spacer Body | 1 | 01-7015 |
| | 2 | "O" Ring (Cooling Water Passage) | 1 | 11-2014 |
| | 3 | "O" Ring (Oil Passage) | 1 | 11-4011 |
| | 4 | "O" Ring (Water Passage) | 1 | 11-2143 |
| | 5 | "O" Ring (Alignment Bushing) | 1 | 11-2228 |
| | 6 | 1" Alignment Bushing | 1 | 01-2276 |
| | 7 | 7/16-20/14 x 3" S/S Stud | 6 | 08-130904161 |
| | 8 | Washer 7/16 " AN S/S Thin | 6 | 08-160900001 |
| \smile | 9 | Nut (7/16-20 Nylock S/S Thin | 6 | 08-090904001 |
| | 10 | 3/8-16 x 4 1/4" Socket Set Screw S/S | 1 | 08-050806211 |
| 510 East Arrow Hwy | 11 | 3/8" AN Washer S/S | 1 | 08-100800001 |
| San Dimas, CA 91773 | 12 | 3/8-16 Thin Nylock Nut S/S | 1 | 08-090806001 |
| 800) 899-8058 (909) 592-6162 Fax (909) 592-6052 | 13 | 3" Coupler | 1 | 01-2165 |
| info@imcomarine.com www.imcomarine.com | 14 | Loctite | 1 | |
| | · · · · · | | | |